FRESH WAVE IAQ CONCENTRATE DILUTION AND MIXING



AIR & SURFACE CONCENTRATE

DIRECTIONS: Mix Air & Surface Concentrate with clean water before using.

DILUTION RATIO: 5 GAL CONCENTRATE (Makes 55 Gallons RTU Liquid) Mix 1 gallon concentrate with 10 gallons of water.

64 OZ CONCENTRATE (Makes 5 Gallons RTU Liquid)

Mix 64 oz. concentrate with 4.5 gallons of water.

Once diluted, Fresh Wave IAQ Air & Surface RTU Liquid can be used in the following applications*:

- TRIGGER SPRAYERS: For immediate, targeted odor control, spray into the air or directly onto water-safe surfaces such as fabrics, upholstery, furniture, counter tops and cabinets.
- FOGGING: Use a full strength mixture at 1.5 oz. per 1,000 cubic feet. For best results, shoot 20 microns or lower.
- ROOM ODORS: Add 2 oz. per gallon of water to a cool mist room humidifier.
- MOP WATER: Mix 8 oz. with 2.5 gallons of water.
- * Suggested amounts. More or less can be used depending on the intensity of the odor.

CARPET & UPHOLSTERY CONCENTRATE

DIRECTIONS: Mix Carpet & Upholstery Concentrate with clean water before using.

DILUTION RATIO: 5 GAL CONCENTRATE (Makes 55 Gallons RTU Additive) Mix 1 gallon concentrate with 10 gallons of water.

64 OZ CONCENTRATE (Makes 5 Gallons RTU Additive)

Mix 64 oz. of concentrate with 4.5 gallons of water.

Once diluted, use 2 oz. RTU Additive per gallon of water in extraction type cleaners or 4 oz. per gallon when using the bonnet method. More or less can be used depending on the intensity of the odor.

LAUNDRY ADDITIVE CONCENTRATE

DIRECTIONS: Mix Laundry Additive Concentrate with clean water before using.

DILUTION RATIO: 5 GAL CONCENTRATE (Makes 55 Gallons RTU Additive) Mix 1 gallon concentrate with 10 gallons of water.

64 OZ CONCENTRATE (Makes 5 Gallons RTU Additive)

Mix 64 oz. concentrate with 4.5 gallons of water.

Once diluted, add 2 oz. RTU Additive to washer during rinse cycle. For difficult odors, let soak for 10 minutes. More or less can be used depending on the intensity of the odor.